

Anti-Microbial Test Information

Test Methods	 The Standard JIS Z 2801, Test for anti-microbial activity and efficacy. The materials were in the form of 2" x 2" flat test samples. The testing process requires that the samples be sterilized, inoculated with a controlled amount of each bacterium, incubated at 35°C for 24 hours, and finally washed and tested for viable bacteria.
Calculation of Antimicrobial Activity (R)	• R = (Log (Bacterial Count of Untreated Control after 24 Hour Incubation))- (Log (Bacterial Count of Test Piece after 24 Hour Incubation))
Criteria for Judging Antimicrobial Activity (R)	• When the sample displays an R value of 2.0 or greater it is judged to have anti- microbial efficacy.
Bacteria Tested and Test Results	 The bacteria tested were Legionella Pneumophila Serogroup 1. The base materials tested were Delta Compounded HDPE, FRP, and Stainless Steel. <u>The Delta AM-HDPE Tower material was the only material deemed Anti-Microbial.</u>
Who Did the Testing	• Special Pathogens Laboratory, The Legionella Experts®, in Pittsburgh, PA., provides expertise in the detection, control, and remediation of Legionella and other waterborne pathogens. Led by Drs. Janet E. Stout and Victor L. Yu, world-renowned pioneers and experts in Legionnaires' disease prevention. They provide total Legionella control, an integrated platform of solutions to prevent outbreaks, save lives, and endeavor to end Legionnaires' disease.